$$e = r - y$$

$$G_{er}(s) = \frac{E(s)}{R(s)} = \frac{R(s) - Y(s)}{R(s)} = 1 - \frac{Y(s)}{R(s)} = 1 - G_{3r}(s) = \frac{1}{1 + (10)P(s)}$$

$$C_{\text{les}}(S) = \frac{1}{1 + ((s))P(s)}$$

$$\lim_{t \to \infty} y(t) = \lim_{s \to 0} s y(s) = \lim_{s \to 0} s \frac{(s) p(s)}{(s) p(s)} \frac{r}{s} = \lim_{s \to 0} \frac{(s) p(s)}{(s) p(s)} r$$

$$\lim_{t\to\infty} e(t) = \lim_{s\to 0} s E(s) = \lim_{s\to 0} s \frac{1}{1+c(s)p(s)} \frac{r}{s} = \lim_{s\to 0} \frac{1}{1+c(s)p(s)} r = 0.7 = 0$$

c)
$$((s) = k_p + \frac{k_i}{5} + k_i S = \frac{k_d S^2 + k_p S + k_i}{S}$$

$$G_{ST}(S) = \underbrace{(CS)P(S)}_{H+((S)P(S)} - \underbrace{\left(\frac{\kappa_d S^2 + \kappa_p s + \kappa_{\bar{t}}}{S}\right)\left(\frac{b_0}{s^2 + a_1 s + a_0}\right)}_{S} = \underbrace{\frac{\left(b_0(\kappa_d S^2 + \kappa_p S + \kappa_{\bar{t}})\right)}{S(S^2 + a_1 s + a_0)}}_{S(S^2 + a_1 s + a_0)}$$

$$= \frac{b_0 \left(K_4 s^2 + K_P s + K_T \right)}{s \left(s^2 + \alpha_1 s + \alpha_0 \right) + b_0 \left(K_4 s^2 + K_P s + K_T \right)} = \frac{b(s)}{\alpha(s)}$$

$$\alpha(s) = s^3 + (a_1 + b_0 k_1) s^2 + (a_0 + b_0 k_P) s + b_0 k_7$$

= $(s - P_1)(s - P_2)(s - P_3) = s^3 + c_2 s^2 + c_1 s + c_0$

$$(2 = a_1 + b_0 k_d) \implies k_d = \frac{c_2 - a_1}{b_0}$$
 $(2 = a_0 + b_0 k_p) \implies k_p = \frac{c_1 - a_0}{b_0}$
 $(3 = b_0 k_i) \implies k_r = \frac{c_0}{b_0}$

Since the poles can be arbitrarily selected, the constants c; will also be arbitrary based on the poles. Since the PID gains are based on (i, the poles of Gyr (an be arbitrarily assigned by adjusting the PID gains.

d)
$$(1/5) = (5+2)(5-(-1+i))(5-(-1-i))$$

 $= (5+2)(5^2-(-1+i))s-(-1-i)s+(-1+i)(-1-i))$
 $= (5+2)(5^2-(-5+is)-(-5-is)+1-i^2)$
 $= (5+2)(5^2+5-is+s+is+2)$
 $= (5+2)(5^2+2s+2)$
 $= (5+2)(5^2+2s+2)$
 $= 5^3+2s^2+2s^2+4s+2s+4$
 $= 5^3+4s^2+6s+4$
 $(2=4)(3-6)(3-4)(3-6)(3-6)$
 $(3+2)(5-1-i$

$$k_p = \frac{c_1 - a_0}{b_0} = \frac{6+2}{1} = 8 \implies [k_p = 8]$$

$$K_d = \frac{C_2 - \alpha_1}{b_0} = \frac{4 - 2}{1} = 2 = D[K_d = 2]$$

OPEN-100P POIES: 0,-10,-20

- NOT a, c

No open-loop zeros => NOT d

$$(I) \rightarrow P$$

$$(II)$$
 $P_2(s) = \frac{s^2 + 9}{s(sho)(sh20)}$

NOT b

Open-loop poles: 0,-10,-20

LANOT a, C

This System has open-up Zerros at ±3i

$$[(II) \rightarrow q]$$

$$\left(\square \right) P_3(s) = \frac{s^2 + 9}{s(s+10)}$$

NOT b,d

Open-loop Poles: 0, -10

Open-100P Zeros: ± 3:

a has poles on imaginal axis but (III) has only real poles => NOT a


$$(\mathbb{H}) \rightarrow C$$


$$(II)$$
 $P_{y}(s) = \frac{s^{2}+9}{S(s+10)(s^{2}+25)}$

Open-100p po les: 0,-10, ±5:

Open-loop Zeros: ±31

$$(\square) \rightarrow \alpha$$







Questions 1d, 4b, 4d, 4e, and 4f are answered in the sections below.

1d)

```
b0 = 1;
a1 = 2;
a0 = -2;
ki = 4;
kp = 8;
kd = 2;
numP = b0;
denP = [1 a1 a0];
P = tf(numP, denP);
numC = [kd kp ki];
denC = [1 0];
C = tf(numC, denC);
Gyr = feedback(P*C, 1);
figure;
step(Gyr);
Ger = 1-Gyr;
figure;
step(Ger);
```

 $\mbox{\ensuremath{\$}}\mbox{The response of y(t)}$ reaches the reference in its steady state and the \ensuremath{\\$}\mbox{error} response reaches 0 at steady state.





Published with MATLAB® R2024b

```
% ECE171A: HW7 Problem 4 -- sample code
% Writen by Yang Zheng
%
%
Note: you can also simulate this problem using ODE
as what you have done in previous assignments.
For LTI systems, we can do the simulations using
transfer functions which are easier for coding.
```


close all


4b)


System parameters


```
m = 1000; % mass
a = 0.2; % lag coefficient
        % another conversion factor
T = 200;
% Dynamics
s = tf('s');
P1 = b/(m*s+c); % transfer function for tau to v
P2 = a*T/(s+a); % transfer function for u to tau
%Case 1: kp=0.01:
% P controller
kp = 0.01;
ki = 0; %0.005;
C = kp + ki/s;
L = C*P2*P1;
              % Loop transfer function
Gyr1 = feedback(L,1); % closed transfer function from r to y
% step response
figure;
step(Gyr1);
title('Step Response (k p=0.01)');
% freqency response
figure;
bode(Gyr1);
title('Bode Plot (k p=0.01)');
%Case 2: kp=0.1:
% P controller
```

```
kp = 0.1;
ki = 0; %0.005;
    = kp + ki/s;
   = C*P2*P1;
                     % Loop transfer function
Gyr2 = feedback(L,1); % closed transfer function from r to y
% step response
figure;
step(Gyr2);
title('Step Response (k_p=0.1)');
% frequency response
figure;
bode (Gyr2);
title('Bode Plot (k p=0.1)');
% The case with kp = 0.01 results in a step response that reaches steady
% state without as many oscillations as the case with kp = 0.1. For the
\mbox{\%} frequency reponses, both cases have a phase decrease from 0 to -180
% degrees and overall, the shapes of both the magnitude and frequency
% responses are the same. However, when kp has a higher value, the
% magnitude response has more of a peak like shape at the crossover
% frequency before dipping and the phase response has a more obvious
% dip shape at this frequency.
```









4d)

Dynamics


```
s = tf('s');
P1 = b/(m*s+c); % transfer function for tau to v
                % transfer function for u to tau
P2 = a*T/(s+a);
% PI controller
kp = 0.1;
ki = 0.005;
   = kp + ki/s;
   = C*P2*P1;
                     % Loop transfer function
Gyr3 = feedback(L,1); % closed transfer function from r to y
disp(Gyr3);
% step response
figure; step(Gyr3)
% freqency response
figure; bode(Gyr3)
```


%When integral control is added, the step response eventually reaches the %steady state value instead of just oscillating around that region of the %graph as it did in proportional control. At lower frequencies, the value

%of the magnitude response is larger (only a little larger in this case due %to the small value of ki). Also, for both the magnitude and phase %responses, the crossover frequency increases resulting in a wider %magnitude and phase plot.

tf with properties:

```
Numerator: {[0 0 100 5]}
 Denominator: {[1000 250 110 5]}
    Variable: 's'
     IODelay: 0
 InputDelay: 0
 OutputDelay: 0
  InputName: {''}
  InputUnit: {''}
 InputGroup: [1×1 struct]
 OutputName: {''}
 OutputUnit: {''}
 OutputGroup: [1×1 struct]
       Notes: [0×1 string]
    UserData: []
        Name: ''
          Ts: 0
    TimeUnit: 'seconds'
SamplingGrid: [1×1 struct]
```






4e)


```
Case 1: kp = 0.01:
          Time domain simulation
% Case 1: peice-wise constant reference
t = 0:0.01:500;
r = zeros(length(t), 1);
for i = 1:length(t)
    if t(i) <= 100
        r(i) = 10;
    elseif t(i) <= 200</pre>
        r(i) = 15;
    elseif t(i) <= 400</pre>
        r(i) = 13;
    else
        r(i) = 10;
    end
end
y = lsim(Gyr1, r, t, 0);
figure; plot(t,r,t,y);
title('Piecewise Reference Tracking (k_p=0.01)');
legend('Reference', 'Velocity');
```


```
set(gcf, 'Position', [100 100 700 300])
% Case 2: periodic references
for period = [60, 50, 40, 20]
   t = 0:0.01:6*period;
                               % time range -- 6 periods
    r = 10 + 2*sin(2*pi/period.*t);
    y = lsim(Gyr1, r, t, 0);
   figure; plot(t,r,t,y);
    title('Periodic Reference Tracking with k p=0.01 and Period =',
num2str(period));
    set(gcf, 'Position', [100 100 700 300])
    h = legend('Reference $r(t)$','Velocity $v(t)$',...
       'location','southeast','Interpreter','latex');
    set(h,'box','off');
    xlabel('Time $t$','Interpreter','latex');
    ylabel('Velocity $v$','Interpreter','latex');
    set(gca, 'TickLabelInterpreter', 'latex', 'fontsize', 10);
end
Case 2: kp = 0.1:
§ _____
         Time domain simulation
% Case 1: peice-wise constant reference
t = 0:0.01:500;
r = zeros(length(t), 1);
for i = 1:length(t)
   if t(i) <= 100
       r(i) = 10;
    elseif t(i) <= 200
       r(i) = 15;
    elseif t(i) <= 400</pre>
       r(i) = 13;
    else
       r(i) = 10;
    end
end
y = lsim(Gyr2, r, t, 0);
figure; plot(t,r,t,y);
title('Piecewise Reference Tracking (k p=0.1)');
set(gcf, 'Position', [100 100 700 300])
% Case 2: periodic references
for period = [60, 50, 40, 20]
                                % time range -- 6 periods
   t = 0:0.01:6*period;
    r = 10 + 2*sin(2*pi/period.*t);
    y = lsim(Gyr2, r, t, 0);
    figure; plot(t,r,t,y);
    set(gcf, 'Position', [100 100 700 300])
    h = legend('Reference $r(t)$','Velocity $v(t)$',...
        'location','southeast','Interpreter','latex');
```


```
set(h,'box','off');
   xlabel('Time $t$','Interpreter','latex');
   ylabel('Velocity $v$','Interpreter','latex');
   title('Periodic Reference Tracking with k p=0.1 and Period =',
num2str(period));
    set(gca, 'TickLabelInterpreter', 'latex', 'fontsize', 10);
end
%Case 3: PI Control
§ ______
         Time domain simulation
% -----
% Case 1: peice-wise constant reference
t = 0:0.01:500;
r = zeros(length(t), 1);
for i = 1:length(t)
   if t(i) <= 100
       r(i) = 10;
   elseif t(i) <= 200</pre>
       r(i) = 15;
   elseif t(i) <= 400
       r(i) = 13;
   else
       r(i) = 10;
   end
end
y = lsim(Gyr3, r, t, 0);
figure; plot(t,r,t,y);
title('Piecewise Reference Tracking (PI Control)');
set(gcf, 'Position', [100 100 700 300])
% Case 2: periodic references
for period = [60, 50, 40, 20]
   t = 0:0.01:6*period;
                               % time range -- 6 periods
    r = 10 + 2*sin(2*pi/period.*t);
    y = lsim(Gyr3, r, t, 0);
   figure; plot(t,r,t,y);
   set(gcf, 'Position', [100 100 700 300])
   h = legend('Reference $r(t)$','Velocity $v(t)$',...
        'location','southeast','Interpreter','latex');
   set(h,'box','off');
   xlabel('Time $t$','Interpreter','latex');
   ylabel('Velocity $v$','Interpreter','latex');
   title('Periodic Reference Tracking with PI Control and Period =',
num2str(period));
    set(gca, 'TickLabelInterpreter', 'latex', 'fontsize', 10);
end
%Proportional control with a small kp does not accurately track the
%reference. The output velocity is much further away than the reference
```

%velocity. When the proportional constant is increased, the controller does
%a better job at tracking the reference with the velocity values being
%closer to the reference. However, this case isn't nearly as accurate the
%PI controller case. Adding integral control allows the controller to track
%the reference much more accurately and at some points, almost exactly.












Periodic Reference Tracking with k_p =0.01 and Period =




Periodic Reference Tracking with k_p =0.01 and Period =








Periodic Reference Tracking with $k_p=0.1$ and Period =




Periodic Reference Tracking with $k_p = 0.1$ and Period =










Periodic Reference Tracking with $k_p = 0.1$ and Period =












Periodic Reference Tracking with PI Control and Period =



Periodic Reference Tracking with PI Control and Period =



Periodic Reference Tracking with PI Control and Period =



4f)

%To ensure safety in this system, it is important to have accurate %reference tracking. For this, the kp and ki values must be properly %adjusted. After experimenting with this simulation, it can be seen that %proportional control is accurate for higher values of kp. However, one %disadvantage of having higher values is the damping that will occur %immediately after activating the system. In cruise control, this high %damping will result in reference tracking errors that could lead to an %accident. In order to get more accurate reference tracking with smaller %proportional constants, it helps to have integral control. However, with %integral control, higher constants will cause much more damping than lower %constants, and it is much more sensitive to parameter changes than a %proportional controller, so it's important to keep ki low. The best %controller is one with a kp value high enough to avoid damping while also %being able to perform reference tracking accurately and a ki value that is %low enough to do the same. Finding this will require an optimization %algorithm that finds the constants that result in the lowest amount of %damping(possibly using peak difference).

Published with MATLAB® R2024b